



Technical Data

©2011 Torco

PRODUCT TECH

FFO FOAM FILTER OIL SPRAY

>>Description

Torco FFO Foam Filter Oil Spray is formulated with special base oils and tackifier additives to prevent moisture and abrasive elements from passing through foam filter elements and entering the engine. FFO is easy to apply and will not dry out, drip or run. FFO will not gum up or clog foam passages.

>>Features

- >Synthetic blend formula
- >Prevents moisture and harmful elements from passing through filter
- >Maximizes airflow for consist jetting and performance
- >Easy to apply and easy to clean up

>>Application

Recommended for use on all foam filter elements found on motorcycle, scooter, ATV and many other 2-cycle and 4-cycle engine applications.

>>Directions

Application: Shake well before use. Hold FFO 6-8 inches away from filter surface and spray an even coat to the outside and inside of the filter. Massage the filter to work in product thoroughly. Do not ring out the filter, as damage may occur to the foam. To provide a good seal, apply a thin layer of Torco Multi-Purpose Waterproof Grease to the sealing surface of the filter. Use latex or rubber gloves when applying filter oil.

Cleaning: Thoroughly wash used filter with light cleaning solvent or a combination of detergent and warm water until all dirt particles are removed from the foam. Rinse with clean water and squeeze out excess. Do not ring out the filter, as damage may occur to the foam. Once filter is completely dry, apply FFO as directed above.

>>Package Sizes / P/N

Description	FFO
13.0 Ounces	T850001RE
12/13.0-Ounce Case	T850001R



TORCO INTERNATIONAL CORPORATION
9145 Milliken Avenue | Rancho Cucamonga, CA 91730
T 909.980.1495 | F 909.980.1465
www.torcousa.com | info@torcousa.com

2/3/2011